

For further help and advice

Phone: 18001 0800 7311 888 (textphone)
0800 7311 888 (telephone)

Email: helpline@rnid-typetalk.org.uk

Fax: 0151 709 8119

www.typetalk.org

RNID Typetalk
Harrington Road
Brunswick Business Park
Liverpool
L3 4DF

In an emergency dial **18000**

Text users calling from abroad - +44 151 494 1260
Hearing users calling from abroad - +44 151 494 2022

The Customer Support Team are available Monday -
Friday 9am-8pm, Saturday and Sunday 9am-5pm.

This leaflet is available in large print and braille.

The Royal National Institute for Deaf People. Registered Office: 19-23 Featherstone Street, London EC1Y 8SL. A company limited by guarantee registered in England and Wales No. 454169, Registered Charity Numbers 207720 (England and Wales) and SC038926 (Scotland).



User Guide: Minicom 6000 Acoustic (with telephone handset) speech impaired (hco)

RNID Typetalk

**Minicom 6000 Acoustic
(with telephone handset)**

Making a call speech impaired (hco)

1. Switch on the M6000
2. Hold down the CTRL key and press number 0 (zero) you will see CODE (AUTOMATIC)
3. Press the ANNOUNCER (spacebar) until you see CODE (CCITT)
4. Hold down the CTRL key and press number 0 (zero) again and CCITT CODE ON will flash on screen
5. Place the telephone handset firmly into the rubber cups
6. Dial 18001 followed by the FULL telephone number including the area code on the TELEPHONE
7. You will then see - TXD Dialling - TXD Ringing - TXD Operator Connected PLEASE WAIT... immediately type SI/HCO
8. The Relay Assistant will respond with THANK YOU , PLEASE HOLD...
9. The Relay Assistant will type the greeting of the hearing person followed by GA
10. You can now type your conversation, when you have finished type GA
11. Wait a few seconds then lift the telephone handset, and listen
12. When the called party has finished speaking, replace the handset in the cups and press the STAR * button on your TELEPHONE, wait three seconds then type your reply.
13. After a short pause you can type your reply
14. To end the call - switch off the textphone and replace the telephone handset

N.B. Each time you wish to listen, repeat steps 11 & 12

**Minicom 6000 Acoustic
(with telephone handset)**

Receiving a call speech impaired (hco)

1. When the telephone rings, place the handset firmly into the rubber cups.
2. Switch on the M6000 and type HELLO
3. You will then see - Call Via TXD - TXD Operator Connected PLEASE WAIT.. immediately type SI/HCO
4. The Relay Assistant will respond with THANK YOU, PLEASE HOLD
5. When you see PLEASE PICK UP NOW IF YOU WISH TO LISTEN
6. Hold down the CTRL key and press the number 0 (zero) you will see CODE (AUTOMATIC)
7. Press the ANNOUNCER (spacebar) until you see CODE (CCITT)
8. Hold down the CTRL key and press number 0 (zero) again and CCITT CODE ON will flash on screen
9. Wait a few seconds then lift the handset and listen
10. When your caller has finished speaking, place the handset back into the cups and press the STAR * button on your TELEPHONE
11. After a short pause you can type your reply
12. To end the call - switch off the telephone and replace the telephone handset

N.B. Each time you wish to listen, repeat steps 9 & 10



INVESTOR IN PEOPLE