

For further help and advice

Phone: 18001 0800 7311 888 (textphone)
0800 7311 888 (telephone)

Email: helpline@rnid-typetalk.org.uk

Fax: 0151 709 8119

www.typetalk.org

RNID Typetalk
Harrington Road
Brunswick Business Park
Liverpool
L3 4DF


In an emergency dial **18000**

Text users calling from abroad - +44 151 494 1260
Hearing users calling from abroad - +44 151 494 2022

The Customer Service Team are available Monday -
Friday 9am-8pm, Saturday and Sunday 9am-5pm.

This leaflet is available in large print and braille.

The Royal National Institute for Deaf People. Registered Office: 19-23 Featherstone Street, London EC1Y 8SL. A company limited by guarantee registered in England and Wales No. 454169, Registered Charity Numbers 207720 (England and Wales) and SC038926 (Scotland).



User Guide:
Pro 100
sending ID / auto ID
seek time

RNID Typetalk

Pro 100

Sending ID / Auto Id

1. Press ON/OFF KEY
2. Press MENU
3. Press right arrow key until you see OPTIONS
4. Press ENTER
5. Press right arrow key (4 times) until your see AUTO ID
6. Press ENTER
7. Press right arrow key to move the brackets around (OFF)
8. Press ENTER
9. Press MENU
10. Press ON/OFF KEY

Pro 100

Seek Time

1. Press on/off
2. Press MENU
3. Press right arrow key until you see OPTIONS
4. Press ENTER
5. Press right arrow key until you see CCITT Parameters
6. Press ENTER
7. Press right arrow key until you see CCITT Seek Time
8. Press ENTER
9. Press Number 9
10. Press ESC



Certificate No. 547



INVESTOR IN PEOPLE