

For further help and advice

Phone: 18001 0800 7311 888 (textphone)
0800 7311 888 (telephone)

Email: helpline@rnid-typetalk.org.uk

Fax: 0151 709 8119

www.typetalk.org

RNID Typetalk
Harrington Road
Brunswick Business Park
Liverpool
L3 4DF

In an emergency dial **18000**

Text users calling from abroad - +44 151 494 1260
Hearing users calling from abroad - +44 151 494 2022

The Customer Support Team are available Monday -
Friday 9am-8pm, Saturday and Sunday 9am-5pm.

This leaflet is available in large print and braille.

The Royal National Institute for Deaf People. Registered Office: 19-23 Featherstone Street, London EC1Y 8SL. A company limited by guarantee registered in England and Wales No. 454169, Registered Charity Numbers 207720 (England and Wales) and SC038926 (Scotland).



User Guide:
minicom 7000 acoustic
(with telephone handset)
text only

RNID Typetalk

Minicom 7000 Acoustic

Making a call text only

1. Switch on the M7000
2. Hold down the CTRL key and press number 0 (zero) you will see CODE (Automatic)
3. Press the ANNOUNCER (spacebar) until you see CODE (CCITT)
4. Hold down the CTRL key and press number 0 (zero) again, CCITT CODE ON will flash
5. Place the telephone handset firmly into the rubber cups
6. Dial 18001 followed by the FULL telephone number including the area code on the TELEPHONE
7. You will then see - TXD Dialling - TXD Ringing - TXD Operator Connected PLEASE WAIT
8. The TRA will type the greeting of the hearing person followed by GA
9. You can now start to Type
10. To end the call - switch off the textphone and replace the telephone handset

Minicom 7000 Acoustic

Receiving a call text only

1. When the telephone rings, place the telephone handset firmly into the rubber cups.
2. Switch on the M7000 and type HELLO
3. You will then see - Call Via TXD - TXD Operator Connected PLEASE WAIT..
4. The Relay Assistant will type what your caller is saying to you
5. When you see GA you can type your reply
6. To end the call - switch off the textphone and replace the telephone handset



INVESTOR IN PEOPLE